






AP9 Installation instruction



		1,5 [□]	2,5 [□]
		MAX	MAX
	Terminals	10	8
	Conductors	30	24
	Anzahl der Klemmen	8	6
	Anzahl der Leiter	24	20

ABB OY
P.O Box 16 (Porvoon Sisäkehä 2)
FI-06101 PORVOO
FINLAND
MAIN exchange tel. +358 10 2211